



HOT START RELAY INSTALL

1. Mount the relay in a safe place as close to the starter as possible.
2. Take the wire from terminal 50 on the solenoid and extend it with 28/0.30 gauge wire. Connect this extension to terminal 86 on the relay.
3. Take a 28/0.30 wire from terminal 85 on the relay to a good earth on the vehicle body/chassis.
4. Take a 65/0.30 wire from terminal 87 to the live terminal of the battery.
5. Take another 65/0.30 wire from terminal 30 on the relay back to terminal 50 on the starter solenoid.

NOTE: It is advisable to always disconnect the vehicles battery before carrying out any work on the electrical system.

